



MAX-31 and MAX-31A

Side Accessory Rails

Installation instructions

This procedure requires average skills. Read instructions completely before proceeding.

Tools and Materials Required:

1/8" Hex Key (Allen Wrench)

Note: The MAX-31 and MAX-31A foregrip has #10-24 screw threads.

Do not use #10-32 screws that are provided with the MAX-11, MAX-11A1 and MAX-10 Side Accessory Rails.

Do not over tighten the screws or you may shear the thread from the polymer grip.

Procedure:

- 1) Point firearm in a safe direction, remove magazine and insure firearm is unloaded and not cocked.
- 2) Place Accessory Rail on side of fore grip.
- 3) Place a drop of Loc Tite 242 (blue) thread locker on end of mounting screws.
- 4) Align mounting holes and place #10-24 x 5/8" long, button head screws into mounting holes and tighten with 1/8" hex key.
- 5) Do not over tighten the screws or you may shear the thread from the polymer grip.