



## M-11/9 and MAX-11

# Internal Suppressor Gas Block

### Installation Instructions:

- 1) Unload M-11/9 and remove magazine. Remove lower receiver from upper receiver.
- 2) Place block into lower receiver, behind magazine well opening.  
Thin end of block should be placed at the rear of the receiver.
- 3) Align holes in block with hammer pin holes in lower receiver. Place retaining pin through lower receiver hammer pin hole, through block and out other side of lower receiver. Secure with E-Clip.

**Note: The Internal Suppressor Gas Block is not compatible with use of a collapsible stock.**