



Sig MPX Stock Adapter

Installation instructions:

This procedure requires average skills. Read instructions completely before proceeding. In general the procedure is to slide the stock adapter in place, install screw and tighten.

Tools and Materials:

5/32" (.156") Hex Key

Loc Tite 242 Blue Thread Locker

Procedure:

- 1) Point firearm in a safe direction, remove magazine and insure firearm is unloaded.
- 2) Stock adapter is packaged with screw installed. Remove screw from stock adapter.
- 3) Slide stock adapter onto rear of gun.
- 4) Place a drop of Loc Tite 242 Blue thread locker on threads of the provided #10-32 Socket Head Cap Screw.
- 5) Align adapter hole with rail slot on back of gun and place screw through hole.
- 6) Use 5/32" (.156") Hex Key to hand tighten screw. When hand tight, turn screw an additional 1/4 turn. If you have a torque driver, tighten to 40 to 45 inch pounds.